

# **READ THIS IMPORTANT WARRANTY NOTICE BEFORE INSTALLATION**

WHEN REPLACING POWER STEERING COMPONENTS IT IS IMPORTANT TO FLUSH THE SYSTEM WITH CLEAN P/S FLUID. FAILURE TO DO SO MAY CAUSE YOUR NEW COMPONENT TO BECOME CONTAMINATED AND INOPERABLE.

IF BORGESON RECEIVES YOUR PUMP OR BOX FOR WARRANTY AND IT IS DEEMED THAT CONTAMINATION WAS THE CAUSE OF THE FAILURE **YOU WILL BE CHARGED** TO CLEAN/SERVICE & REPAIR YOUR ITEM.

## **Bleeding Power Steering**

All power steering systems are designed to be self-bleeding but sometimes they need a little help.

After installing new components, fill the reservoir and let it sit for a few minutes. **Before starting the vehicle**, raise and support the front end of the vehicle and turn the wheels back and forth slowly to allow the steering box to draw fluid, be sure to keep the reservoir full.

When the fluid level stops dropping, start the vehicle and continue turning the wheels slowly lock-to -lock. When the fluid level remains constant and there is no evidence of air bubbles in the fluid, the system is fully bled.

**NEW ADDRESS**

**Borgeson Universal Company**  
**9 Krieger Drive**  
**Travelers Rest, SC 29690**  
**[www.borgeson.com](http://www.borgeson.com)**